

USER GUIDE AND SUPPLEMENTAL INFORMATION

# Force of Nature Pro Appliance

For Use with Force of Nature Pro Activator Capsules

## Introduction

This kit contains: + Pro

Appliance & power cord

+ 3 Spray Bottles

+ 10 Pro Activator Capsules

+ You'll use 1 or 2 Pro Activator Capsules each time you make your multi-purpose cleaner and disinfectant, depending on batch size.

+ Quick Start Guide

+ User Guide

Please read this entire guide before using your Force of Nature Pro Appliance

## Warnings



Important safety instructions Read all instructions before using this product.



Caution: To reduce the risk of fire, electrical shock, damage to the product or injury:

The Force of Nature Pro Appliance is only designed for use in a 110/120/240V outlet.

To avoid electric shock, do not touch the Pro Appliance with wet hands.

If the cord or plug appears damaged, return the cord to Force of Nature by emailing us at [support@forceofnatureclean.com](mailto:support@forceofnatureclean.com) and we will replace it.

Power only with included 40V power supply from Merryking, model: MKI-4000250G8

Any attempts to repair the Force of Nature Pro Appliance without written permission from Force of Nature will void the warranty and could cause personal injury to the consumer and/or result in severe damage to the unit.

Do not pull, carry, lift or drag the Pro Appliance by the power cord.

Remove the power plug from its outlet by grasping the plug itself and pulling gently.

Use only for cleaning and disinfecting. Do not consume electrolyzed water. Use only in well-ventilated areas.

Avoid contact with eyes. If in eyes, rinse well with water. If irritation persists, seek medical attention.

This product should not affect skin. However, if skin becomes irritated, rinse skin with plenty of water. If irritation persists, seek medical attention.

Do not use to formulate your own homemade cleaner or disinfectant.

Do not clean the Force of Nature bottles with anything but tap water.



Caution: To ensure proper solution concentrations and optimal disinfecting power, follow these instructions:

Do not leave Force of Nature cleaner and disinfectant solution in the Pro Appliance. ALWAYS POUR SOLUTION INTO A SPRAY BOTTLE IMMEDIATELY AFTER COMPLETION OF A CYCLE.

Use Force of Nature multi-purpose cleaner and disinfectant within 14 days after making it. Discard left over solution after 14 days and rinse only with tap water before running a new cycle. Force of Nature maintains its power for 2 weeks. To help you keep track of time, there is a green light around the bottom of the Pro Appliance. After the 2 weeks are up, the light will turn red to remind you to make a fresh batch. If you don't want to keep your Pro Appliance plugged in, write the expiration date on the back of the Spray Bottle.

Add only the required number of Pro Activator Capsules per batch. Do not run more than one cycle per batch of cleaner and disinfectant solution.

Do not use cleaner prior to light ring on Pro Appliance turning completely green.

### TO CLEAN

+ Spray the surface, cloth, sponge, cloth or mop and then wipe dry.

### TO SANITIZE

+ Clean the surface.

+ Spray the surface until thoroughly wet.

+ Wait 1 minute and then wipe the surface.

### TO DISINFECT

+ Clean the surface.

+ Spray the surface until thoroughly wet.

+ Wait 2 minutes and then wipe the surface or let air dry naturally.

Store Force of Nature multi-purpose cleaner and disinfectant in the Spray Bottle at room temperature away from direct sunlight.

# Operating Instructions

1. Fill the Pro Appliance with cool water to the desired Fill Line. 2. Plug the power cord into the Pro Appliance and into the outlet. 3. Squeeze in the full contents of one 10ml Pro Activator Capsule if you are creating 32 oz of cleaner, or two 10ml Pro Activator Capsules if you are creating 64 oz of cleaner. Wait 10 seconds for the Activator Capsule solution to disperse.
4. Press the Start button corresponding to the amount of cleaner you want to make: push the button labeled 1 for 32 oz, or the button labeled 2 for 64 oz. Blue lights will begin pulsing, and the lights will begin to transition to green as the cycle continues. The cleaner will be ready after the light ring is completely green.
5. Unplug the Pro Appliance and pour your Force of Nature cleaner into the Spray Bottles. Rinse the Pro Appliance with water before plugging it back in. Press the start button twice in rapid succession to start your day counter.

Force of Nature maintains its efficacy for 2 weeks (14 days).

To help you keep track of time, there is a light ring around the bottom of the Pro Appliance that will be green when you first make your cleaner. When you have only 2 days left, the light ring will turn to yellow. At day 14, the light ring will be red, indicating your cleaner has expired – time to make a fresh batch! If you don't want to keep the Pro Appliance plugged in, write the expiration date on the back of the bottle.

When the Spray Bottle is not in use, store upside down on a drying rack.



Empty capsules can be recycled

## Color Code Guide for Light Ring

Blue: Your cleaner and disinfectant solution is being made. Green:

Your cleaner and disinfectant solution is ready. Yellow: Your cleaner and disinfectant solution has two days remaining.

Half Red: The Pro Appliance has not been properly filled with water and/or the proper number of Capsules.

All Red: The cleaner and disinfectant solution has expired or the electrolyzing process did not properly complete.

## Troubleshooting

If nothing happens after pressing the desired Start Button: Unplug the Pro Appliance, wait 20 seconds, then plug it back in at both the outlet and in back of the appliance. Press desired Start Button again. If no response, plug the Pro Appliance into a different outlet and try again.

If the light ring around your Pro Appliance is half red:

The Pro Appliance has not been properly filled with water and/ or the appropriate number of 10 ml Pro Activator Capsule(s). Check to make sure that the Pro Appliance is filled to the desired Fill Line with cool water and that you added the corresponding required Pro Activator Capsule(s): One Pro Activator Capsule for Fill Line 1, or 2 Pro Activator Capsules for Fill Line 2.

If the light ring around your Pro Appliance is all red after you have made a batch:

The cleaner has expired. If the light ring around your Pro Appliance is all red during the making process, the cycle did not properly complete. Unplug the power cord from the Pro Appliance, pour out your solution and re-fill with water to the desired Fill Line. Add the contents of one Pro Activator Capsule for Fill Line 1, or two Pro Activator Capsules for Fill Line 2. Re-plug the Pro Appliance in and press the desired Start Button. If you encounter the issue again, please contact our support team at 1-888-985-8099 or by email at [support@forceofnatureclean.com](mailto:support@forceofnatureclean.com).

If at first the Spray Bottle won't dispense:

Pull the trigger a number of times until the Spray Bottle dispenses. Also ensure you have opened the nozzle of the spray head by twisting it counter-clockwise to open.

## Ordering Force of Nature Supplies

Force of Nature supplies can be purchased by logging in at [www.forceofnatureclean.com/Pro](http://www.forceofnatureclean.com/Pro) or a local distributor/reseller.

## Warranty



For details, please go to [forceofnatureclean.com/warranty](http://forceofnatureclean.com/warranty)

We're here to help!


Reach out to us at 888-985-8099 or go to [www.forceofnatureclean.com/Pro](http://www.forceofnatureclean.com/Pro) with any questions.

HCI Cleaning Products LLC

PO Box 1145

Westford, MA 01886





#### SUPPLEMENTAL INFORMATION

# Force of Nature Pro Activator Capsules

For Use with Force of Nature Pro Appliance

#### DIRECTIONS FOR USE OF FORCE OF NATURE ACTIVATOR CAPSULE (TO GENERATE HYPOCHLOROUS ACID SOLUTION)

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling. Users must follow all directions for use that are listed in the Force of Nature Pro Appliance User Guide.

Note: Force of Nature Pro Activator Capsules are for single use.

The Force of Nature Pro Appliance is designed to use electricity, potable tap water and Force of Nature Pro Activator Capsule to create HOCl (hypochlorous acid) solution. This conversion is accomplished using a process called electrolysis that employs an electrolytic cell. Force of Nature Pro Appliance makes solution on demand as initiated by the User.

1. Fill the Pro Appliance with cool water to the desired Fill Line.
2. Plug the power cord into the Pro Appliance and into the outlet.
3. Squeeze in the full contents of one 10ml Pro Activator Capsule

if you are creating 32 oz of cleaner, or two 10ml Pro Activator Capsules if you are creating 64 oz of cleaner. Wait 10 seconds for the Activator Capsule solution to disperse.

4. Press the Start button corresponding to the amount of cleaner you want to make: push the button labeled 1 for 32 oz, or the button labeled 2 for 64 oz. Blue lights will begin pulsing, and the lights will begin to transition to green as the cycle continues. The cleaner will be ready after the light ring is completely green.
5. Unplug the Pro Appliance and pour your Force of Nature cleaner into the Spray Bottles. Rinse the Pro Appliance with water before plugging it back in. Press the start button twice in rapid succession to start your day counter.

This process generates a Hypochlorous Acid solution of 220 ppm Available Chlorine. Users must refer to the directions for use of Hypochlorous acid solution for hard, non-porous surface disinfection.

#### PRECAUTIONARY STATEMENTS

Physical or Chemical Hazards: Force of Nature Activator Capsule content is not compatible with other chemicals such as bleach or hydrogen peroxide, or any other cleaner or disinfectant.

DO NOT MIX Force of Nature Activator Capsules or Hypochlorous Acid solution with any other product.

Hazards to Humans and Domestic Animals: CAUTION Causes moderate eye irritation. Avoid contact with eyes. When handling the product, wear safety glasses or goggles if splashing is anticipated. Wash thoroughly with soap and water after handling and before eating, chewing gum, using tobacco or using the toilet.

#### FIRST AID

Call a poison control center or doctor for treatment advice. Have the product container or label with you when calling a poison control center, doctor or going for treatment. You may also contact the National Pesticide Information Center (NPIC) 1-800-858-7378 for emergency medical treatment.

If in eyes: Hold eye open and rinse slowly and gently with water for 15-20 minutes. Remove contact lenses, if present, after the first 5 minutes, then continue rinsing eye.

#### DIRECTIONS FOR USE OF HYPOCHLOROUS ACID SOLUTION

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling

Disinfection of Hard, Non-Porous Surfaces using Force of Nature Solution Spray

To Clean, Disinfect and Deodorize Hard Non-Porous Surfaces: Pre-clean surface. Spray Force of Nature disinfecting solution on surface until thoroughly wet. Allow surface to remain wet for 2 minutes. Wipe surface with clean cloth or towel or let air dry.

Sanitization of Hard, Non-Porous Surfaces using Force of Nature Solution Spray

To Clean and Sanitize Hard Non-Porous Surfaces: Pre-clean surface. Spray Force of Nature solution on surface until thoroughly wet. Allow surface to remain wet for 1 minute. Wipe surface with clean cloth or towel or let air dry.

Solution(s) are effective for up to 14 days from production date. After 14 days discard and refill bottle with fresh solution. Always use a Force of Nature approved spray bottle and label to identify product in use.

Solution can be used immediately upon production, or stored for up to 14 days in cool area out of direct sunlight in a closed Force of Nature approved spray bottle.

The Force of Nature Pro Appliance is designed to use electricity, potable tap water and Force of Nature Activator Capsules to make an antimicrobial HOCl (hypochlorous acid) solution. This conversion is accomplished by using a process called electrolysis that employs the use of an electrolytic cell. Force of Nature Electrolyzed Water Device will make solution per demand and only require User input when making solution.

Use Sites: For use on hard, non-porous surfaces

The Force of Nature Pro Appliance Solution is designed for use on hard non-porous surfaces in Household, Commercial and Institutional settings. It cleans, deodorizes, sanitizes and disinfects.



For full list of Use Sites and Use Surfaces, and Storage and Disposal instructions, please go to [forceofnatureclean.com/supplemental-information](http://forceofnatureclean.com/supplemental-information)

<b>PATHOGEN</b>	<b>STRAIN</b>	<b>CONTACT TIME</b>
<b>ORGANISMS SUPPORTED FOR DISINFECTION</b>		
Pseudomonas aeruginosa	ATCC 15442	2 min
Staphylococcus aureus	ATCC 6538	2 min
Escherichia coli (E. Coli)	ATCC 112229	2 min
Salmonella enterica	ATCC 10708	2 min
Listeria monocytogenes	ATCC 19117	2 min
Methicillin-resistant Staphylococcus aureus*	ATCC 33592	2 min
Feline Calicivirus surrogate for Norovirus*	VR-782	2 min
Influenza A virus *	VR-544	2 min
<b>ORGANISMS SUPPORTED FOR FOOD CONTACT SANITIZATION</b>		
Salmonella enterica subspecies enterica serovar Typhi	ATCC 6539	1 min

\*Dwell times based on required submitted EPA antimicrobial testing

#### Germ List:

Pseudomonas aeruginosa, Staphylococcus aureus, Salmonella enterica, Escherichia coli (E. coli), Listeria monocytogenes, Methicillin Resistant Staphylococcus aureus – MRSA, Influenza A Virus Strain A/Hong Kong/8/68, Feline Calicivirus Strain F9

#### Viruses List:

Influenza A Virus Strain A/Hong Kong/8/68, Feline Calicivirus Strain F9

#### Flu Viruses List:

Influenza A Virus Strain A/Hong Kong/8/68

## STORAGE AND DISPOSAL

Do not contaminate water, food or feed by storage or disposal or cleaning of equipment.

**Pesticide Storage:** Store in a closed plastic container in a cool, dry area away from heat and sunlight to avoid deterioration. Do not store near easily oxidizable materials acids and reducers. In case of spill, flush area with large quantities of water.

**Pesticide Disposal:** Wastes resulting from the use of this product must be disposed of on-site or at an approved waste disposal facility. Product or rinsates that cannot be used must be diluted with water before disposal in a sanitary sewer.

**Container Handling:** Refillable container. Refill container with Force of Nature solution only. Do not reuse this container for any other purpose. Cleaning before refilling is the responsibility of the refiller. Cleaning the container before final disposal is the responsibility of the person disposing the container. To clean the container before final disposal fill container half way with water and shake vigorously. Dispose of rinsate as pesticide waste. Repeat this rinsing procedure two more times. Then offer for recycling or puncture and dispose of in a sanitary landfill, or by incineration, or by procedures allowed by state and local authorities.