



#### SUPPLEMENTAL INFORMATION

## Force of Nature Activator Capsules

for use with Force of Nature Appliance

Thank you for purchasing Force of Nature Activator Capsules.

#### We're here to help!

Reach out to us at 888-985-8099 or [support@Forceofnatureclean.com](mailto:support@Forceofnatureclean.com) with any questions.

### DIRECTIONS FOR USE OF FORCE OF NATURE ACTIVATOR CAPSULE (TO GENERATE HYPOCHLOROUS ACID SOLUTION)

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling. Users must follow all directions for use that are listed in the Force of Nature Appliance User Guide.

#### NOTE:

Force of Nature Activator Capsules are for single use.

The Force of Nature Appliance is designed to use electricity, potable tap water and Force of Nature Activator Capsules to make an antimicrobial HOCl (hypochlorous acid) solution. This conversion is accomplished by using a process called electrolysis that employs the use of an electrolytic cell. Force of Nature Electrolyzed Water Device will make solution per demand and only require Consumer input when making solution.

1. Ensure the rubber cover is covering the power jack on the back of the Electrolyzer Appliance. Fill to fill line with tap water (12 oz). Maximum recommended water hardness is 100 ppm to ensure optimal device longevity.
2. Add in full contents of one Activator Capsule (3 ml) to Electrolyzer Appliance. (Use only Force of Nature Activator Capsules when making Electrolyzed Water Solution). Wait 10 seconds for solution to disperse.
3. Plug power cord into Electrolyzer Appliance and into outlet.
4. Press start button on front of Electrolyzer Appliance once. Blue lights will begin pulsing, then will transition to green. The cleaner will be ready after the light ring is completely green, in about 6-8 minutes.
5. Unplug Electrolyzer Appliance and pour cleaner into spray bottle. Rinse Electrolyzer with water before plugging back in. Hit start button twice quickly to start day counter.

This process generates a Hypochlorous Acid solution of 220 ppm Available Chlorine.

Users must refer to the directions for use of Hypochlorous acid solution for hard, non-porous, non-food contact surface disinfection.

## PRECAUTIONARY STATEMENTS

Physical or Chemical Hazards: Force of Nature Activator Capsule content is not compatible with other chemicals such as bleach or hydrogen peroxide.

## HAZARDS TO HUMANS AND DOMESTIC ANIMALS:

### CAUTION

Causes moderate eye irritation. Avoid contact with eyes. When handling the product, wear safety glasses or goggles if splashing is anticipated. Wash thoroughly with soap and water after handling and before eating, chewing gum, using tobacco or using the toilet.

### FIRST AID

Call a poison control center or doctor for treatment advice. Have the product container or label with you when calling a poison control center, doctor or going for treatment. You may also contact the National Pesticide Information Center (NPIC) 1-800-858-7378 for emergency medical treatment.

### IF IN EYES:

Hold eye open and rinse slowly and gently with water for 15-20 minutes. Remove contact lenses, if present, after the first 5 minutes, then continue rinsing eye.

Hypochlorous Acid Solution

220 ppm Available Chlorine

Disinfectant for hard, non-porous surfaces

## DIRECTIONS FOR USE OF HYPOCHLOROUS ACID SOLUTION

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling

Hard, Non-Porous Surface Disinfection using Force of Nature Final Solution Spray

### TO CLEAN AND DISINFECT AND DEODORIZE HARD NON-POROUS SURFACE:

Pre-clean surface. Spray Force of Nature disinfecting solution on surface until thoroughly wet. Allow surface to remain wet for 2 minutes. Wipe surface with clean cloth or towel or let air dry.

Solution(s) are effective for up to 14 days from production date. After 14 days discard and refill bottle with fresh solution. Always use a Force of Nature approved spray bottle and label to identify product in use.

Solution can be used immediately upon production, or stored for up to 14 days in cool area out of direct sunlight in a closed Force of Nature approved spray bottle.

Force of Nature Disinfectant Solution(s) are intended for use in household, commercial, institutional, healthcare, dental office, veterinarian and hospitality housekeeping. It cleans and disinfects.

PATHOGEN	STRAIN	CONTACT TIME
<b>ORGANISMS SUPPORTED FOR DISINFECTION</b>		
Pseudomonas aeruginosa	ATCC 15442	2 min
Staphylococcus aureus	ATCC 6538	2 min
Salmonella enterica	ATCC 10708	2 min
Listeria monocytogenes	ATCC 19117	2 min
Methicillin-resistant Staphylococcus aureus	ATCC 33592	2 min
Feline Calicivirus surrogate for Norovirus	VR-782	2 min
Influenza A virus	VR-544	2 min
<b>ORGANISMS SUPPORTED FOR FOOD CONTACT SANITIZATION</b>		
Salmonella enterica subspecies enterica serovar Typhi	ATCC 6539	1 min

For full list of Use Sites and Use Surfaces, and Storage and Disposal instructions, please go to [forceofnatureclean.com/supplemental-information](http://forceofnatureclean.com/supplemental-information)



## DISINFECTION ORGANISM LIST

\* Salmonella enterica (Salmonella), Staphylococcus aureus (Staph), Methicillin Resistant Staphylococcus aureus (MRSA), Pseudomonas aeruginosa (Pseudomonas), Listeria monocytogenes (Listeria), Feline Calicivirus, Strain F-9, Influenza A virus

### \* Qualified Germs List

Kills Pseudomonas aeruginosa, Staphylococcus aureus, Salmonella enterica, Listeria monocytogenes, Methicillin Resistant Staphylococcus aureus - MRSA and Influenza A Virus, Strain A/Hong Kong/8/68, Feline Calicivirus, Strain F9

## SANITIZATION ORGANISM LIST

\* Salmonella enterica (Salmonella), Staphylococcus aureus (Staph), Methicillin Resistant Staphylococcus aureus (MRSA), Pseudomonas aeruginosa (Pseudomonas), Listeria monocytogenes (Listeria), Feline Calicivirus, Strain F-9, Influenza A virus

HCI Cleaning Products LLC  
Forceofnatureclean.com  
888-985-8099  
support@Forceofnatureclean.com  
PO Box 1145  
Westford, MA 01886