



#### USER GUIDE AND SUPPLEMENTAL INFORMATION

# Force of Nature Appliance and Activator Capsules

Please read this entire guide before using the products

## This box contains:

- + Electrolyzer Appliance & power cord
- + Force of Nature Activator Capsules (use 1 each time you make your multi-purpose cleaner & disinfectant)
- + Reusable Spray Bottle
- + Quick Start Guide
- + User Guide & Supplemental Information

## Operating Instructions

1. Ensure the rubber cover is covering the power jack on the back of the Electrolyzer Device Appliance. Fill Electrolyzer to the line on the back of bottle with cool water (12 oz). Note, water should be less than 100 ppm hardness for optimum device longevity.
2. Add in full contents of one Activator Capsule (3 ml) to Electrolyzer Appliance. (Use only Force of Nature Activator Capsules when making Electrolyzed Water Solution). Wait 10 seconds for solution to disperse.
3. Plug power cord into Electrolyzer Appliance and into outlet.
4. Press start button on front of Electrolyzer Appliance once. Blue lights will begin pulsing, then will transition to green. The cleaner will be ready after the light ring is completely green, in about 6-8 minutes.
5. Unplug the Electrolyzer and pour your cleaner into the Spray Bottle. Put spray-head on Spray Bottle. Rinse the Electrolyzer with water and immediately plug it back in. Hit the start button twice quickly to start your day counter.

#### NOTE:

Always ensure the rubber cover is covering the power jack when filling or emptying the Electrolyzer.

This process generates a Hypochlorous Acid solution of 220 ppm Available Chlorine.

Force of Nature maintains its efficacy for 2 weeks. To help you keep track of time, there is a light ring around the bottom of the Electrolyzer that will be green when you first make your cleaner. Every 2 days, one section of the green lights will go dark. When you have only 2 days left, the one remaining green light will turn to yellow.

At day 14, the entire base will be red, indicating your cleaner has expired – time to make a fresh batch! If you don't want to keep the Activator Base plugged in, write the expiration date on the back of the bottle.

If filling multiple bottles, unplug power for 30 seconds between cycles. When the Spray Bottle is not in use, store upside down on a drying rack.

## Color Code Guide

Blue: Your cleaner is being made.

Green: Your cleaner is ready.

Yellow: Your cleaner has two days remaining.

Half Red: The Electrolyzer has not been properly filled with water and/or a Capsule, you may not be using the correct power cord, or you might not have waited 10 seconds after adding the Capsule.

All Red: The cleaner has expired or the electrolyzing process did not properly complete.

## Troubleshooting

If nothing happens after pressing the Start Button, please unplug the Electrolyzer, wait 20 seconds, then plug it back in and ensure that the plug is properly plugged in. Press Start Button again. If it still does not respond, please try another outlet.

If the light ring around your Electrolyzer is half red, make sure you filled the Electrolyzer up to the line with water and one Capsule, waited 10 seconds after adding the Capsule, and that you're using the correct power cord.

If the light ring around your Electrolyzer is all red after you have made a batch, the cleaner has expired. If the light ring around your Electrolyzer is all red during the making process, the cycle did not properly complete. Unplug the power cord from the Electrolyzer, pour out your solution and re-fill with water and the contents of one capsule. Re-plug the Electrolyzer in and hit start. If you encounter the issue again, please contact our support team at 1-888-985-8099 or by email at [support@forceofnatureclean.com](mailto:support@forceofnatureclean.com).

If at first the Spray Bottle won't dispense, pull the trigger a number of times until the Spray Bottle dispenses. You may also need to twist the nozzle of the spray head to the closed position and then slowly re-open it while pulling the trigger to find an optimal spray mode.

# Warnings



**Important safety instructions**  
**Read all instructions before using this product.**



**Caution: To reduce the risk of fire, electrical shock, damage to the product or injury:**

- + The Force of Nature appliance is only designed for use in a 110/120/240V outlet.
- + To avoid electric shock, do not touch the appliance with wet hands.
- + If the cord or plug appears damaged, return the cord to Force of Nature by emailing us at [support@forceofnatureclean.com](mailto:support@forceofnatureclean.com) and we will replace it.
- + To be only powered by certified switching power supply from Merryking Enterprises (HK) Co Ltd, model MKS-0903000.
- + Any attempts to repair the Force of Nature appliance without written permission from Force of Nature will void the warranty and could cause personal injury to the consumer and/or result in severe damage to the unit.
- + Do not pull, carry, lift or drag the appliance by the power cord. Remove the power plug from its outlet by grasping the plug itself and pulling gently.
- + Use only for cleaning and disinfecting.
- + Do not consume electrolyzed water.
- + Use only in well-ventilated areas.
- + Avoid contact with eyes. If in eyes, rinse well with water. If irritation persists, seek medical attention.
- + This product should not affect skin. However, if skin becomes irritated, rinse skin with plenty of water. If irritation persists, seek medical attention.
- + Do not use to formulate your own homemade cleaner or disinfectant.
- + Do not clean the Force of Nature bottles with anything but tap water.
- + This appliance is not intended for use by people (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- + Children should be supervised when using the appliance.



**Caution: To insure proper solution concentrations and optimal disinfecting power, follow these instructions:**

- + Use Force of Nature multi-purpose cleaner and disinfectant within 14 days after making it. Discard left over solution after 14 days and rinse only with tap water before running a new cycle. Force of Nature maintains its power for 2 weeks. To help you keep track of time, there is a light around the bottom of the Electrolyzer. After the 2 weeks are up, the base will turn red to remind you to make a fresh batch. If you don't want to keep your Electrolyzer plugged in, write the expiration date on the back of the Spray Bottle.

- + Do not overfill or under-fill the Spray Bottle.
- + Add only one Activator Capsule per batch.
- + Do not run more than one cycle per bottle.
- + Do not use cleaner prior to light ring on Electrolyzer Appliance turning green.
- + To clean, spray the surface or cloth and then wipe the surface dry.
- + To Disinfect:
  - + Clean the surface.
  - + Spray the surface until thoroughly wet.
  - + Wait 2 minutes and then wipe the surface.
- + Store Force of Nature multi-purpose cleaner and disinfectant in the Spray Bottle at room temperature away from direct sunlight.

## NOTE:

Force of Nature Activator Capsules are for single use.

# Supplemental Information

## FORCE OF NATURE ACTIVATOR CAPSULES FOR USE WITH FORCE OF NATURE APPLIANCE

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling. Users must follow all directions for use that are listed in the Force of Nature Appliance User Guide.

## NOTE:

Force of Nature Activator Capsules are for single use.

1. Ensure the rubber cover is covering the power jack on the back of the Electrolyzer Appliance. Fill Electrolyzer to the line on the back of bottle with cool water (12 oz). Note, water should be less than 100 ppm hardness for optimum device longevity.
2. Add in full contents of one Activator Capsule (3 ml) to Electrolyzer Appliance. (Use only Force of Nature Activator Capsules when making Electrolyzed Water Solution). Wait 10 seconds for solution to disperse.
3. Plug power cord into Electrolyzer Appliance and into outlet.
4. Press start button on front of Electrolyzer Appliance once. Blue lights will begin pulsing, then will transition to green. The cleaner will be ready after the light ring is completely green, in about 6-8 minutes.
5. Unplug the Electrolyzer and pour your cleaner into the Spray Bottle. Put spray-head on Spray Bottle. Rinse the Electrolyzer with water and immediately plug it back in. Hit the start button twice quickly to start your day counter.

## DIRECTIONS FOR USE OF HYPOCHLOROUS ACID SOLUTION

Hard, Non-Porous Surface Disinfection using Force of Nature Final Solution Spray

To Clean and Disinfect and Deodorize Hard Non-Porous Surface:

Pre-clean surface. Spray Force of Nature disinfecting solution on surface until thoroughly wet. Allow surface to remain wet for 2 minutes. Wipe surface with clean cloth or towel or let air dry.

Solution(s) are effective for up to 14 days from production date. After 14 days discard and refill bottle with fresh solution. Always use a Force of Nature approved spray bottle and label to identify product in use.

Solution can be used immediately upon production, or stored for up to 14 days in cool area out of direct sunlight in a closed Force of Nature approved spray bottle.

Force of Nature Disinfectant Solution(s) are intended for use in household, commercial, institutional, healthcare, dental office, veterinarian and hospitality housekeeping. It cleans and disinfects.

Use Sites: For use on hard, non-porous surfaces



For full list of Use Sites and Use Surfaces, and Storage and Disposal instructions, please go to [forceofnatureclean.com/supplemental-information](http://forceofnatureclean.com/supplemental-information)

This process generates a Hypochlorous Acid solution of 220 ppm Available Chlorine.

Users must refer to the directions for use of Hypochlorous acid solution for hard, non-porous, non-food contact surface disinfection.

## PRECAUTIONARY STATEMENTS

Physical or Chemical Hazards: Force of Nature Activator Capsule content is not compatible with other chemicals such as bleach or hydrogen peroxide.

## HAZARDS TO HUMANS AND DOMESTIC ANIMALS:

### CAUTION

Causes moderate eye irritation. Avoid contact with eyes. When handling the product, wear safety glasses or goggles if splashing is anticipated. Wash thoroughly with soap and water after handling and before eating, chewing gum, using tobacco or using the toilet.

#### FIRST AID

Call a poison control center or doctor for treatment advice. Have the product container or label with you when calling a poison control center, doctor or going for treatment. You may also contact the National Pesticide Information Center (NPIC) 1-800-858-7378 for emergency medical treatment.

If in eyes: Hold eye open and rinse slowly and gently with water for 15-20 minutes. Remove contact lenses, if present, after the first 5 minutes, then continue rinsing eye.

PATHOGEN	STRAIN	CONTACT TIME
<b>ORGANISMS SUPPORTED FOR DISINFECTION</b>		
<i>Pseudomonas aeruginosa</i>	ATCC 15442	2 min
<i>Staphylococcus aureus</i>	ATCC 6538	2 min
<i>Escherichia coli</i> (E. Coli)	ATCC 112229	2 min
<i>Salmonella enterica</i>	ATCC 10708	2 min
<i>Listeria monocytogenes</i>	ATCC 19117	2 min
Methicillin-resistant <i>Staphylococcus aureus</i> *	ATCC 33592	2 min
Feline Calicivirus surrogate for Norovirus *	VR-782	2 min
Influenza A virus *	VR-544	2 min
<b>ORGANISMS SUPPORTED FOR FOOD CONTACT SANITIZATION</b>		
<i>Salmonella enterica</i> subspecies <i>enterica</i> serovar Typhi	ATCC 6539	1 min

\*Dwell times based on required submitted EPA antimicrobial testing

#### Germes List:

*Pseudomonas aeruginosa*, *Staphylococcus aureus*, *Salmonella enterica*, *Escherichia coli* (E. coli), *Listeria monocytogenes*, Methicillin Resistant *Staphylococcus aureus* – MRSA, Influenza A Virus Strain A/Hong Kong/8/68, Feline Calicivirus Strain F9

#### Viruses List:

Influenza A Virus Strain A/Hong Kong/8/68, Feline Calicivirus Strain F9

#### Flu Viruses List:

Influenza A Virus Strain A/Hong Kong/8/68

## Warranty



For details, please go to [forceofnatureclean.com/warranty](http://forceofnatureclean.com/warranty)

#### We're here to help!

Reach out to us at 888-985-8099 or [support@Forceofnatureclean.com](mailto:support@Forceofnatureclean.com) with any questions.

For even more information, visit [Forceofnatureclean.com](http://Forceofnatureclean.com).

HCI Cleaning Products LLC

[Forceofnatureclean.com](http://Forceofnatureclean.com)

888-985-8099

[support@Forceofnatureclean.com](mailto:support@Forceofnatureclean.com)

PO Box 1145

Westford, MA 01886

